INSTRUCTIONS PHILCO MODEL 7051 TUBE TESTER

Operates on 110-120 volts, 60 cycles, a.c.
Tube Complement: 1—6X5 (rectifier).
Short Indicator Lamp: Neon lamp, ¼ watt, 105-125
volts, screw base.
Pilot Lamp: 6-8 volts.

Test Methods Employed

The Philco Model 7051 Tube Tester uses the emission test for quality determination. The control settings given in the chart, with the average run of normal tubes, will provide readings near the central portion of the GOOD area on the meter; with a little practice, the operator will be able to determine the differences in readings for normal, slightly weak, and dead tubes. A separate quality test is applied to each section of multi-purpose tubes.

The short test gives positive indication of a short existing between one element of a tube and any one (or more) of the remaining elements.

Ballast tubes may also be tested in the Model 7051 Tube Tester; see the ballast-tube section of the chart for operating instructions.

Supplementary Tube Data

In order to keep the tube-test chart for the Philoo Model 7051 Tube Tester up to date, Philoo will, from time to time, issue data for the testing of newly released tubes. Contact your Philoo distributor for this information.

Spare Socket Holes

One additional socket hole (covered by a bakelite cap) is provided on the panel of the tester. It may be used for installing a socket to accommodate a special-purpose tube, or may be reserved for tubes of future development.

PHILCO CORPORATION

ACCESSORY DIVISION PHILADELPHIA 34, PA.

HOW TO OPERATE THE PHILCO MODEL 7051 TUBE TESTER

For correct operation of this tester, the following procedure should be used:

1. Line Control

Insert the power-cord plug into a 110-to-120-volt, 60-cycle power source. Turn the LINE control to the right (clockwise) from the OFF position, and note that the PILOT Indicator Lamp glows. Hold the TEST control in the LINE position, and adjust the a-c voltage by turning the LINE CHECK mark in the center of the scale. Leave the LINE control in this position, and release the TEST control.

2. Filament Control

Refer to the data in the chart for the type of tube to be tested, and turn the FIL. (filament voltage) control to the position indicated in the Filament Control column.

3. Toggle Switches

Nine toggle switches, operating in slots marked with letters at each end, are used to switch the separate tube elements into the neon-lamp accircuits when making the short test, or to connect the proper elements to the rectified-voltage supply and meter when making the quality test, as directed by the chart.

Each of these switches has three positions. Before proceeding with any test, make sure that the switches are set according to the instructions given below, under SHORT TEST. Tubes must not be inserted in the sockets until all switches are set to their proper positions; otherwise, damage to the tube tester or the tube may result.

4. Short Test

a. Before placing the tube in the tester, refer to the toggle-switch setting, listed in the Short Test column, for the type of tube to be tested. For many types of tubes, one or more toggle-switch settings are indicated by small letters. Refore the tube is placed in the socket, the switches thus indicated must be set to these positions; the switches indicated by the large letters

are manipulated, as described below, after the tube is placed in the socket. If no large letters appear, the small letters indicate the complete short test (in one operation).

b. To make the short test, observe the SHORT Indicator Lamp while throwing the toggle switches, one at a time, to the positions indicated in the chart by large letters; return each switch to its center position before operating the next switch. If the lamp glows steadily when one or another of the switches is thrown to its listed position, a shorted tube is indicated.

Note: When each toggle switch is in its short test position, if there is no glow of the lamp, it is advisable to tap the tube on its sides with the fingers. If this causes flashes of light or a steady glow in the lamp, intermittently shorting tube elements are indicated, and the tube should be replaced.

For a few types of tubes, *two* of the letters indicating toggle-switch positions are topped by a heavy line. The two switches thus identified must be operated at the same time, to prevent a false short indication.

5. Quality Test

- a. Turn the LOAD control to the position indicated for the type of tube to be tested, in the Load Control column of the chart.
- b. Place the toggle switches in the positions indicated in the *Quality Test* column of the chart. If no toggle-switch settings are indicated for the quality test, the switches should remain in their center positions.
- c. Turn the TEST control to the QUALITY position, and read the condition of the tube on the meter.
- d. It will be noted that for certain types of tubes (multi-purpose), the chart lists two or three LOAD-control and toggle-switch combinations. Make the *Quality Test* as directed in steps a, b, and c above, for each of the combinations given.
 - Note: To aid in localizing radio and tube troubles, the classifications of sections of multi-purpose tubes, according to the grouping of elements, are listed in the Tube Section column.

Replacing Rectifier Tube (6X5) in Model 7051 Tube Tester

If the tube tester should fail to give any meter indications, or should give false readings on tubes of known condition, the trouble is probably caused by failure of the type 6X5 rectifier tube; this tube may be replaced as follows:

- Remove the power-cord plug from the a-c power source.
- 2. Remove the ten Phillips machine screws from around the edges of the front panel.
- 3. Lift the tester from its case, replace the rectifier tube, and reassemble the tester.

Replacing Short Indicator Lamp in Model 7051 Tube Tester

The neon lamp used for the short test may be replaced without removing the tester from its case. The lamp used is a 4-watt, 105-to-125-volt, "crew-base bulb.

NOTE:

Improved versions of tubes are occasionally brought out after the original design, and are usually identified by adding a letter after the original type designation. Unless specifically listed on the chart, these tubes should be tested in accordance with the data given for the original type.

BALLAST TUBE TESTING WITH THE PHILCO MODEL 7051 TUBE TESTER

The Philco Model 7051 Tube Tester gives a complete continuity test on ballast tubes, providing a separate test for each ballast section. To test ballast tubes, proceed as follows:

- 1. Turn the LINE control on.
- 2. Turn the LOAD control to position 1.
- 3. Set the TEST control to SHORT.
- 4. Set the FIL control to position 0.
- 5. Throw all toggle switches to their center positions, and insert the ballast tube in the tester.
- 6. Refer to the following chart for the listing of the type of tube to be tested. For a tube having more than one ballast section, the combinations of toggle-switch settings required for testing the separate sections are listed one below the other, and enclosed in a box.
- 7. Observe the SHORT Indicator Lamp as the switches are set. If the lamp glows steadily with the switches set to the indicated combination, the tube (or the section under test) is good. If the lamp fails to glow with the switches set to any one of the indicated combinations, the tube has an open section, and should be replaced.
 - Note A: With some ballast tubes, the SHORT Indicator Lamp will normally glow before the toggle switches are operated; the tube test, however, depends upon the glowing of the lamp when the switches are set to the indicated combinations.
 - Note B: A continuity test between pin 7 and other pins cannot be made on the tester; this test must be made with an ohmmeter.

TUBE	TOGGLE	TUI	TOGGLE SWITCHES
1A1	R	2LR21	
1B1	R		G
101	R	2UR22	
1D1	R	21/02	G
1D2	A	2VR2	15 A
454	В	3	R
1E1	R	3	GS
1E2	A	3CR24	
454			CG
1F1	R		GS
161	R	3ER24	
1J1	R		CG
1K1	R	3.25	A
1L1	R	4	R
1N1	R	4A1	R
1P1	R	4A21	R
101	R	4AZI	GS
1R1G	R	4XR30	
151G	R		CG
1T1G	R	5	R
101	R	5B	D
1V1	R		F
1W1	BS	5E1	R
1X1	R	6B	D
171	R		GS
1Z1	R	6.125	
2	R		CG

KEY TO TUBE-SECTION DESIGNATIONS

BP Beam Power D Diode H Hexode

Hp Heptode M Mixer Os Oscillator P Pentode
T Triode
TE Tuning Eye
Te Tetrode

00A to 1C5GT

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
00A	5	ABCDEF	9		
0Y4	1		8	ACT	Gas
0Z4	0	ABCDEF	14	CT	
01A	5	ABCDEF	9		
1A3	1	eĀFB	11	BE	
1A4	1	AB	8	T	
1A5GT	1	ABCDEF	4		
1A6	2	ABCDEF	4		
1A7GT	1	ABCDEF	9		
1AB5 ·	1	cghABF	6	CGH	
1AF4	1	eBF	6	E	
1AF5	1	BDEF	6 14	B DEF	PD
1AX2	1	abghnp	14	ABGHNPT	D
1B3GT	1	kmop	8	KMOPT	
1B4	2	ABCDEF	4		-
1B5 1B5/25\$	2	ABCDEF	9 14 14	BD ACD ABC	T D D
1B7GT	1	ABCDEF	6		
1B8GT	1	ABCDEF Grid Cap	4 4	B ADE*	BP T
1C5GT	1	ABCDEF	6		

^{*}Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
106	2	ABCDEF	4 14	AC BD	Os M
1076	2	ABCDEF	9 2	AD BET*	Os M
1D5G	2	ABCDEF	4		
1D7G	2	ABCDEF	9		
1D8GT	1	ABCDEF	6 8	ABCD E*	TP
1E4G	1	ABCDEF	. 4		
1E5GT	2	ABCDEF	4		
1E7G/GT	2	ABCDEF	4	AD BE	P
1F4	2	ABCDEF	6		
1F5G	2	ABCDEF	6		
1F6	2	ABCDEF	4 11 11	BC ABD* ACD*	PDD
1F7G	2	ABCDEF	4 11 11	DE ABD* ABE*	PDD
1G4GT	-1	ABCDEF	4		
1G5G	1	ABCDEF	6		
1G6GT	1	ABCDEF	4 4	AD BE	T
1H4G	2	ABCDEF	4		
1H5GT	1	ABCDEF	6 8	E A*	TD

^{*}Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Control	Toggle Switches Quality Test	Tube
1H6G	2	ABCDEF	4 8 8	DE ABD ABE	TOD
1J5G	2	ABCDEF	6		
1J6G/GT	2	ABCDEF	6	AD BE	I
1L4	1	eABF	13	E	17/3
1L6	1	BDEF	9		
1LA4	1	ABCDEF	13	1	
1LA6	1	ABCDEF	4 14	AEF BD	Os M
1LB4	1	ABCDEF	6	**	
1LB6	1	ABCDEF	4		
1LC5	1	eghABDF	6	EGH	7
1LC6	1	ABCDEF	13		
1LD5	1	ABCDEF	6		
1LE3	1	ABCDEF	6		
1LG5	1	oABCDF	10	0	
1LH4	1	ABCDEF	13 11	D AF	TD
1LN5	1	oABCDF	6	0	
1N5GT	1	ABCDEF	6	San and a second	
1N6GT	1	ABCDEF	14	B ADE	P
1P5GT	.1	ABCDEF	6		
105GT	1	ABCDEF	7	201	
1R4/1294	1	ACD	8	C	
1R5	1	eABCDF	6	E	

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
154	1	eBCD	7	E	
1\$5	1	ABCDEF	10		
1SA6	1	ABCD	13		
114	1	eABCDF	10	E	
1T5GT	1	ABCDEF	6		
1U4	1	eABF	4	E	
105	1	ABCDE	4		
106	1	BDEF	8		H
1V	6	ABCDEF	5	В	
1V2		Cannot b	e i	ested	
1X2A	1	abghnp	8	ABGHNPT	D
172	1		4	BDFKOT	
2A3	3	ABCDEF	5		
2A4G	3	eABCDF	11	E	
2A5	3	ABCDEF	7	C	
2A6	3	ABCDEF	7 11 11	BCD ABC* ACD*	D
2A7	3	ABCDEF	7	ACD BCE	Os M
2A7S	3	ABCDEF	5	C	
2AF4	3	bnrsAFE	4	BNERS	UHF
2B6	3	ACDEF	7	C	
287	3	ABCDEF	8 8	BCE ABCD* ACDE*	P D D
204	2	BDE	5	D	

^{*}Grid cap off.

TUBE TYPE	Filament	Toggle Switches Snort Test	Load	Toggle Switches Quality Test	Tube
2021/1642	6	ABCDE	6	ABCE ACD*	Ī
2022	6	C	8	CT	
2026	6	C	8	CT Plate Cap	
2D21	6	begnAF	4	ABEGNS	
2E5	3	ABCDEF	6	C	
2E24	4	bdfhACE*	7	BCDFH	
2E26	6	bdfAE	5	BDF	
2E30	4	bdAEF	7	BDS	
2G5	3	ABCDEF	6	C	
25/45	2	ABC	8	AC BC	D
2T4	3	bnrsAFE	4	BNERS	UHF
2V2	1	ehlmn	8	EHLMNT	
2V3G	3	Grid Cap	8	T	
2W3GT	3	mABDEF	4	M	
2X2	3	ABCDEF	2	T	
2X2A	3	Cap	4	T	
2X2/879	3	ABCDEF	2	T	
2Y2	2	Cap	4	GHT	
272 272/G84	3	ABCDEF	4		
3A2	4	abghnp	4	ABGHNP	T
3A3	4	Kmop	8	KMOPT	
3A4	1	ehĀFBD	6	EH	
3A5	1	dhABEF	6	ABDH DEFH	T

TUBE TYPE	Control	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
3A8GT	1	ABCDE	6 4 4	CEPG EPGH CPGH	PDT
3AL5	4	benACFG	2 2	BNR BEN	D
3AU6	4	bngAEF	2	ABNGS	P
3AV6	4	bnAEFGS	4 11 11	ABEFNRS ABENG ABFNG	T D D
3B5GT	1	hcADE	6	НМ	
387/1291	1	dhABC	4	ABDH CDFH	T
3BA6	4	bgnAEF	11	BGN	
3BC5	4	bnrAGEF	2	ABGNT	
3BE6	4	bnAEFGS	11	ABN	
3BN6	4	bnAEFG	2	BNRT	
3BY6	4	bnAEFGS	11	ABN	
3BZ6	4	bnrAEFG	4	ABGNT	
3C5GT	1	cABDEF	2	CH	
3C6/XXB	1	cABDEF	6	AC AM	T
3CB6	4	bnrAGEF	4	ABGNT	
3CF6	4	bnrAGEF	11	ABGN	P
3CS6	4	bnAEFGS	14	ABN	
3D6/1299	1	chABF	7	СН	
3E5	1	ehABD	4	EH	P
3E 6	1	chABDF	5	СН	

TUBE TYPE	Filamen	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
3LE4	1	cABDEF	6	C	and the same
3LF4	1	chABF	7	CH	
304	1	ehAFBD	4	EH	
3Q5GT	1	mABDEF	7	MG	
3S4	1	ehĀFBC	4	EH	
3V4	1	ehABD	4	EH	
4A6G	2	mgABDEF	6	AMDG BMEG	T
4BQ7	6	ABCDEF	2 2	ADEF BCEF	T ₁ T ₂
4BZ7	5	CDEF	3	ADEF BCEF	T
5AM8	5	ABDEF	3	AC A	DP
5AN8	5	eABCDF	4 5	BCEF ADE	TP
5AQ5	5	bgnAEF	8	ABGN	
5AS8	5	ABCDEF	2 2	F E	DP
5AT8	5	ABCDEF	3	BCEF ADE	TP
5AU4	5	mABDEF	4	MD BM	D
5AV8	5	ABCDEF	4	A C	TP
5AW4	5	mABDEF	4	MD BM	D_1 D_2
5AX4GT	5	m _	10 10	BM DM	D

3A8GT to 5AX4GT

TUBE TYPE	Filament	Toggle . Switches Short Test	Control	Toggle Switches Quality Test	Tube
5AZ4	5	aDF	9	AD AF	D
5BE8	5	ABCDEF	4	EF	
5BK7	5	ABCDEF	2 2	ADEF BCEF	T ₁
5J6	5	bnAEFG	2 2	ABGNS BGN	T
5R4GY	5	mABDEF	4	BM DM	D D
5T4	5	mABDEF	7	M D BM	D
5T8	5	ABCDF	10	ABC	I
			7 5 5	ACF BCF ABCEF	D D D
5U4G	5	mABDEF	4	MD BM	.D D
5U8	5	ABDEFCF	3	cannot be tested	TP
5V4G	5	mABDEF	4 4	MD BM	D
5V6GT	5	ABCDEF	5	C	
5W4GT	5	mABDEF	4	F 0=	D
5X3	5	AB	4		
5X4G	5	cABDEF	4		D

				N.	_
TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
5X8	5	ABCDEF	2	BDE ABCF	P
5Y3GT	5	mABDEF	4	MD BM	D
5Y4G	5	cABDEF	4	AC CE	D
5Z3	5	ABCDEF	4	A B	D
5Z4G	5	mABDEF	4	BM MD	D
6A3	6	ABCDEF	5		
6A4 6A4/LA	6	ABCDEF	7		
6A5G	4	mABDEF	5	MG	
6A6	6	ABCDEF	7 7	ADE BCE	T
6A7	6	ABCDEF	7	ACD BCE	M Os
6A7S	6	ABCDEF	5	C	
6A8GT	6	ABCDEF	7	ACD BCE	M Os
6AB4	6	bnSG	3	. BNSG	
6AB5/6N5	6	ABCDEF	10	C	
6AB6G	6	ABCDEF	6	C	
6AB7/1853	6	ABCDEF	3	E	
6AC5GT	. 6	ABCDEF	7	C	
6AC7/1852	6	ABCDEF	3	E	
6AD6G	6	ABCDEF	14	CT	

5AZ4 to 8AD6G

TUBE TYPE	Filament	Toggle Switches Short Test	Control	Toggle Switches Quality Test	Tube
6AD7G	6	ABCDEF	6 7	ACD C	TP
6AE5G	6	ABCDEF .	5	C	
6AE5GT	6	ABCDEF	3	C	
6AE6G	6	ABCDEF	7	C	
6AE7GT	6	ABCDE	7 7	C	T
6AF4	6	bnrsĀFE	4	BNERS	UHF
6AF5GT	6	ABCDEF	5	C	
6AF6G	6	ABCDEF	14	CT	
6AG5	6	bnrAGEF	2	ABGNT	
6AG7	6	ABCDEF	3	E	
6AH4	6	CEF	1	C	T
6AH5G	6	BCDF	2	C	
6AH6	6	bnrAEF	1	BGNS	
6AH7GT	6	csABDEF	6	ACDF BCDE	T
6AJ4	6	abefgmDS	14	ABDEFGMS	
6AJ5	6	abgnEFS	2	ABGNS	
6AK5	6	abgnEFS	2	ABGNS	
6AK6	6	bnAEFG	.7	BGNS	
6AL5	6	benACFG	2 2	BNR BEN	D
6AL7GT	6	ABCDEF	11	C	
6AM4	6	abefgmDS	14	ABDEFGMS	
6AM8	6	ABDEF	3	AC A	DP

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
6AN4	6	bnrsĀFE	4	BNERS	UHF
6AN5	6	abgnEF	3	ABGNS	
6AN6	6	F	11	BDEF ADEF	D
6AN8	6	eABCDF	4 5	BCEF ADE	TP
6AQ5	6	bgnAEF	8	ABGN	
6AQ6	6	bnrsAG	2	ABNRS	
6AQ7GT	6	bcADEF	7 12 12	ABCF BCDEF ABCDE	D
6AR5	6	bnAEFS	11	ABN	
6AR6	6	bmAEFG	4	BFMR	
6AR8	6	ABCDEG	3	C	
6AS5	6	bnAEFG	5	BNR	
6AS6	6	bnAEFG	2	ABGNS	
6AS7	6	csABDEF	3	ACS BCS	T
6AS8	6	ABCDEF	2 2	F E	DP
6AT6	6	bnEFG	4 11 11	ABEFNRS ABENG ABFNG	T D D
6AT8	6	ABCDEF	3 14	BCEF ADE	TP
6AU4	6	cAE	4	AC	
6AU5	6	ACEF	3	A	P

6AD7G to 6AU5

TUBE TYPE	Fllament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
6AU6	6	bngAEF	2	ABNGS	P
6AU7	6	hABCDEF	7 7	EH FH	T
6AU8	6	ABCDEF	3	A B	TP
6AV5	6	ACEF	1	A	P
6AV6	6	bnAEFGS	4 11 11	ABEFNRS ABENG ABFNG	DDD
6AW8	6	ABCEDF	2 2	ABCF ABDE	TP
6AX4GT	6	cAE	5	AC	D
6AX5GT	6	ACE	10	AC EC	D
6AX7	6	hBCDEF	7 7	DEFH BCEFH	T
6AX8	6	ABDECF	Cann 3	ot be tested	TP
6AZ8	6	ABCEDF	4	CEF	
6B4G	6	ABCDEF	5		
6B5	6	ABCDEF	10	C	,
6B6G	6	ABCDEF	5 9 8	CDE ACD* ACE*	T D D
6B7	6	ABCDEF	6 8 8	BCE ACDE* ABCD*	PDD

*Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
6B8G	6	ABCDEF	6 8 8	CDE ABCE* ABCD*	PDD
6BA6	6	bgnAEF	11	BGN	
6BA7	6	ABCDEF	3	E	
6BC4	6	aBCDEF	2	AB	
6BC5	6	bnrAGEF	2	ABGNT	
6BC7	6	acBDEF	333	ABCDE ACDEF ABCEF	D ₁ D ₂ D ₃
6BD4	6	EF	8	F	
6BD5GT	6	ACF	3	Α	
6BD6	6	bnrAEF	7	BGNS	
6BE6	6	bnAEFGS	11	ABN	71
6BF5	6	bnrsAEF	4	ABGN	
6BF6	6	bnrsAEF	10 10 10	ABEGNS ABEGNS ABEGNS	D ₂
6BG6G	6	ACE	5	Α	
6BH6	6	bgnAEF	3	ABGNS	
6BJ6	6	bgnAEF	3	ABGNS	
6BK4	6	E	8	ABCDF	
6BK5	6	ABCEF	4	В	
6ВК6	6	bnEFG	14 8 8	ABEFNRT ABEGN ABFGN	T D ₂ D ₁
6BK7	6	ABCDEF	2	ADEF BCEF	T ₂

6AU6 to 6BK7

TUBE TYPE	Filament	Toggle Switches Short Test	Control	Toggle Switches Quality Test	Tube
6BL4	6	csA	3	A	
6BL7GT	6	csABDEF	2 2	ABCF ABCDES	T
6BN6	6	nbAEFG	2	BNRT	
6BQ6	6	ACDEF	2	C	P
6BQ6GT	6	CED	9	ABCEF	
6BQ7	6	ABCDEF	2	ADEF BCEF	T ₁
6BT6	6	bnEFG	11 8 8	ABEFNRT ABEGN ABFGN	T D D
6BX7	6	csABDEF	4	ABCF ABCDES	T ₁ T ₂
6BY5	6	FC	5 5	CDF CEF	D
6BY6	6	bnAEFGS	11	ABN	
6BZ6	6	bnrAEFG	4	ABGNT	
68Z7	6	CDEF	3	ADEF BCEF	T
6C4	6	bnsFG	2	BGNS	
6C5GT	6	ABCDEF	7	C	
606	6	ABCDEF	7	C	
6C7	6	ABCDEF	7 .8 .8	BCE ABC* ACE*	D D
6C8G	6	ABCDEF	7 7	BCDE ACD*	T
6CA5	6	bnAEFG	3	BNR	

^{*}Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
6CB5	6	ABCFDE	4	ĀB	
6CB6	6	bnrAGEF	4	ABGNT	
6CD6G	6	ACE	10	AE	
6CF6 -	6	bnrAGEF	11	ABGN	P
6CG7	6	ABCDEF	7	F E	T ₁
6CL6	6	adEFC	8	AD	P
6CM6	6	ABEC	4	C	
6CM7	6	ABECEEF	4	AEF	T ₁
6CR6	6	bnAEFG	12 11	ABN BEFGN	PD
6CS6	6	bnAEFGS	14	ABN	
6CU6	6	ACDEF	4	C	P
6D4	6	bnER	3	BENR	
6D5G	6	ABCDEF	7	C	
6D6	6	ABCDEF	7	C	
6D7	6	ABCDEF	7	C	
6D8G	6	ABCDEF	10	ACD BCE	Os M
6DB6	6	BnrAGEF	4	ABGNT	
6DC6	6	bnrAEFS	14	ABNR	
6DE6	6	bnrAGEF	2	ABGNT	
6DG6	6	ABCDEF	- 4	C	
6DQ6	6	ACDEF	4	C	
6E5	6	ABCDEF	6	C	

6BL4 to 6E5

TUBE TYPE	Filament	Toggle Switches Short Test	Control	Toggle Switches Quality Test	Tube
6 E6	6	ABCDEF	10	ADE BCE	T
6E7	6	ABCDEF	7	C	
6F5GT	6	ABCDEF	5	C	A. A. Company
6F6GT	6	ABCDEF	7	C	
6F7	6	ABCDEF	10	BCE ACD*	P
6F8G	6	ABCDEF	5 2	BCDE ACD*	T
6G6G	6	ABCDEF	7	C	
6H4GT	6	ABCDEF	10	C	To sept of the sep
6H6GT	6	ABCDEF	7	ACD CDE	D
614	6	befnAR	1	ABGNS	
6J5GT	6	ABCDEF	5	C	
6,16	6	bnAEFG	2 2	ABGNS BGN	T
6J7GT	6	ABCDEF	7	C	
6J8G	6	ABCDEF	2 2	BCE ACD*	Hp T
6K5GT	6	ABCDEF	7	C	1
6K6GT	6	ABCDEF	7	C	
6K7GT	6	ABCDEF	2	C	
6K8GT	6	ABCDEF	11 2	BCE ACD*	H
6L5G	6	ABCDEF	7	C	
6L6G	6	ABCDEF	5	С	

^{*}Grid cap off.

TUBE TYPE	Filamen	Toggle Switches Short Test	Load	Toggla Switches Quality Test	Tube
6L7G	6	ABCDEF	7 5	ACDE	Os M
6N4	6	bngAFES	4	ABFNRS	
6N5	6	ABCDEF	10	C	
6N6G	6	ABCDEF	10	C	
6N7GT/G	6	ABCDEF	7 7	ACD BCE	T
6P5GT	6	ABCDEF	7	C	
6P7G	6	BCDEF	7	KBCG KCDE	P
606G/6T7G	6	ABCDEF	5 8 8	CDE ACD* ACE*	TDD
607GT	6	ABCDEF	7 8 8	CDE ACD* ACE*	T D D
607MG	6	ABCDEF	5 8 8	CDE ACD* ACE*	DDD
6R6G	6	ABCDEF	7	C	P
6R7	6	ABCDEF	7 8 8	CDE ACD* ACE*	DD
6R7G	6	ABCDEF	10 8 8	CDE ACD* ACE*	DD
6R7GT	6	ABCDEF	7 8 8	CDE ACD* ACE*	DD

^{*}Grid cap off.

TUSE TYPE	Fllament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
654	6	D	5	D	
6S7G	6	ABCDEF	7	C	
658GT	6	ceABDFS	4 8	ACE BCDEF*	T&D D
6SA7GT	6	ABCDEF	5	В	
6SB7Y	6	ABCDEF	3	В	
6SC7GT	6	cABDEF	7 7	ABCH BCDE	T
6SD7GT	6	ABCDEF	2	E	
6SF5GT	6	cABDEF	5	C	
6SF7G/GT	6	cABDE	8	ABCD ACE	DP
6SG7G/GT	6	aeBCDF	2	AEF	
6SH7GT	6	aeBCDF	3	AE	
6SJ7GT	6	ABCDEF	5	E	
6SK7GT	6	ABCDEF	5	E	
6SL7GT	6	csABDEF	7 7	ABCF ABCDES	T
6SN7GT	6	csABDEF	2 2	ABCF ABCDES	T
6SQ7GT	6	cABDEF	7 8 8	ACDES ABCD ABCE	T D D
6SR7GT	6	cABDEF	7 8 8	ACDES ABCD ABCE	D D
6557	6	ABDE	7	E	

^{*}Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
6517	6	cABDEFG	4 11 11	ACDES ABCD ABCE	DDD
6SU7GTY	6	csABDEF	7	ABCF ABCDES	I
6SV7	6	cABDEF	3	AECS ADBC	T D
6SZ7	6	cABDEF	4 11 11	ACDES ABCD ABCE	T D D
6T4	6	bnrsAFE	4	BNERS	T
6T 5	6	ABCDEF	6	C	
6T7G	6	ABCDEF	7 8 8	CDE ACD* ACE*	DDD
618	6	ABCDF	10 7 5 5	ABC ACF BCF ABCEF	DDD
6U5/6G5	6	ABCDEF	6	C	
6U6GT	6	ABCDE	2	C	
6U7G	6	ABCDEF	7	C	
6U8	6	ABDEFCF	3	Cannot be tested ACF	TP
6V3			e t	ested	
6V5G	6	cABDEF	5	C	
6V6GT/G	6	ABCDEF	5	C	

6S4 to 6V6GT/G

*Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggla Switches Quality Test	Tube
6V7G	6	ABCDEF	7 8 8	CDE ACD* ACE*	T D D
6W4GT	6	cAE	3	AC	
6W5G	6	ABCDEF	7	AC CE	D
6W6GT	6	ABCDEF	3	C	
6W7G	6	ABCDEF	5	C	
6X4	6	bgnF	4	BFGNS BGN	D
6X5GT/G	6	ABCDEF	7	AC CE	D
6X8	6	ABCDEF	2	BDE ABCF	PT
6Y3G	6	Cap	4	GHT	
6Y5	6	ABCDEF	5 5	BC BD	D
6Y6GT	6	ABCDEF	1.1	C	
6Y7G	6	ABCDEF	7 7	ACD BCE	T
6Z3	6	ABCDEF	. 5	В	To be
674/84	6	ABCDEF	7 7	AC BC	D D
625	6	kBCDEF	4	KBC KBD	D
6Z7G	6	ABCDEF	5	ACD BCE	I

^{*}Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
6ZY5G	6	ABCDEF	7	AC CE	D
7A4	6	ABCDEF	5	C	
7A5	6	ABCDEF	3	C	
7A6	6	ABCDEF	4	ABC ACF	D
7A7	6	ABCDEF	5	C	
7A8	6	ABCDEF	11	BCD ACEF	M Os
7AB7/1204	6	adfgmB	10	ABDFGMS	T
7AD7	6	ABCDEF	3	C	
7AF7	6	ABCDEF	2 2	A C	T
7AG7	6	eABCDF	3	CE	
7AH7	6	ABCDEF	3	C	
7AJ7	6	ABCDE	5	CE	
7AK7	6	ABCDEF	3	C	P
7AU7	6	hABCDEF	7	EH	T
			7	FH	T
7B4	6	ABCDEF	5	C	
7B5	6	ABCDEF	7	C	
7B6	6	cdABEF	2 8 8	CDEF ABCDE ABCDF	TDD
7B7	6	ABCDEF	7	C	
7B8	6	ABCDEF	11,	BCD ACEF	M Os
7C4/1203A	6	CD	4	C	
705	6	ABCDEF	5	C	

6V7G to 7C5

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
706	6	cdABEF	7 8 8	CEDF ABCDE ABCDF	T D D
707	6	ABCDEF	7	C	
7D7	6	ABCDEF	3	C	
7E5/1201	6	asBCDF	2	ADFS	
7E6	6	cdABEF	7 8 8	CDEF ABCDE ABCDF	DDD
7E7	6	ABCDEF	6 11 11	BCD ABCEF ACDEF	PDD
7F7	6	ABCDEF	7 7	A C	T
7F8	6	agmBDEF	6	ABDEMR ADEFGMS	T
7F8/S	6	agmBDEF	6	ABDEMR ADEFGMS	T
767/1232	6	ABCDEF	1	C	
768/1206	6	ABCDEF	2 2	BCEF ABDF	Te Te
7H7	6	ABCDEF	2	C	
7,17	6	ABCDEF	7 7	ACD BCD	T Hp
7K7	6	ABCDEF	11 11 7	ABCDE ABCDF ACEF	D D T
717	6	ABCDEF	2	C	

TUBE TYPE	Filament	Toggle Switches Short Test	Lond	Toggle Switches Quality Test	Tube
7N7	6	ABCDEF	7	A C	T
707	6	ABCDEF	5	C	
7R7	6	ABCDEF	5 11 11	ACDEF ABCEF	P D D
757	6	ABCDEF	4	ACDE BC	Hp
7 V7	6	ABCDEF	1	C	
7W7	6	cdABEF	2	CD	
7X6	6	AC	3	ABC AFC	D
7 X7	6	cdABEF	4 4 4	ABCDE ABCDF CDEF	DDT
7Y4	6	ABCDEF	7	BC CF	D
724	6	BCDF	4 4	CDF BCD	D
10	7	ABCDEF	4		
12A	5	ABCDEF	7		
12A5	6	mgADEF*	7	BMG	
12A6GT	8	ABCDEF	7	C	
12A7	8	ABCDEF	6 5	BCE ACDE*	PD
12A8GT	8	ABCDEF	11 7	BCE ACD	M Os

7C6 to 12A8GT

*Grid cap off.

TUSE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
12AB5	8	AFBEC	4	С	
12AH7	8	csABDEF	4	ACDF BCDE	T
12AH7GT	8	ABCDEF	3	E	
12AL5	8	benACFG	5 5 4	BNR BENS ABEFNRS	DDT
12AQ5	8	bgnAEF	8	ABGN	
12AT6	8	bnEFG	11	ABENG ABFNG	D
12AT7	6	hABCDEF	3	FH EH	T
12AU6	8	bgnAEF	3	BGNS	
12AU7	6	hABCDEF	7 7	EH FH	T
12AV5	8	ACEF	1	A	P
12AV6	8	bnAEFGS	4 11 11	ABEFNRS ABEGN ABFGN	T D D
12AV7	6	hABCDEF	14	CFH DEH	T
12AW6	8	bnrAEF	3	ABNRS	
12AX4GT	8	cAE	5	AC	D
12AX7	6	hBCDEF	7	DEFH BCEFH	T
12AY7	6	hABCDEF	4	FH EH	T
12AZ7	6	hABCDEF	3	ADEFH BCEFH	T

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
12B4	8	oA	1	OA	T
12B7G	. 8	ABCDEF	5	C	
12B8GT	8	dABCEF	5	BCEF ABDF*	P
12BA6	8	bnAEFGS	3	BGNS	
12BA7	8	ABCDEF	3	E	
12BD6	8	abnEFGS	4	ABGNS	
12BE6	8	bnAEFGS	11	ABN	
12BF6	8	bnAEF	10 11 11	ABEFNRS ABNEG ABNEG	T D D
12BH7	6	hCDEF	3	BCEFH ADEFH	T
12BK5	8	ABCEF	4	В	
12BK6	8	bnEFG	14 8 8	ABEFNRT ABEGN ABFGN	T D D
12BQ6GT	8	ACEDF	2	C	
12BR7	6	hABCDEF	3 4 4	EH BFH CFH	T D D
12BV7	6	behACDF	4	ABEH	
12BY7	6	beAF	4	ABE	P
12BZ7	6	hABCDEF	3	FH EH	T
1205	8	bnAEFG	5	BNR	
1208	8	ABCDEF	6	CDE	

^{*}Grid cap off.

12AB5 to 12C8

TUBE TYPE	Filamen	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
12CR6	8	bnAEFG .	12 11	ABN BEFGN	PD
12CS6	8	bnAEFGS	14	ABN	
12CU6	8	ACDEF	4	C	P
12DQ6	8	ACDEF	4	C	
12E5GT	8	ABCDEF	10	C	
12F5GT	8	ABCDEF	5	C	
1264	8	bnsFG	4	BNGS	T
12H6	8	ABCDEF	7 7	ACD CDE	D
12J5GT	8	ABCDEF	5	C	
12J7GT	8	ABCDEF	7	C	
12K7GT	8	ABCDEF	7	C	
12K8G T	8	ABCDEF	11 2	BCE ACD	T
12L6GT	8	ABCDEF	2	C	
12L8GT	8	bACDEFS	5	В	
1207GT	8	ABCDEF	5 8 8	CDE ACD* ACE*	T D D
12S8GT	8	ceABDF*	7 8 8	ACDEF ABCEF* BCDEF* ABCDE*	D ₁ D ₂ D ₃
12SA7GT	8	ABCDEF	5	В	
12SC7	8	cABDEF	6	ABCH BCDE	T

^{*}Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
12SF5GT	8	cABDEF	2	C	
12SF7G/GT	8	cABDE	8	ABCD ACE	DP
12SG7	8	aeBCDF	2	AEF	
12SH7GT	8	aeBCDF	3	AE	
12SJ7GT	8	ABCDEF	5	E	
12SK7GT	8	ABCDEF	5	E	
12SL7GT	8	csABDEF	7	ABCF ABCDES	T
12SN7GT	8	csABDEF	2 2	ABCF ABCDES	T
12SQ7GT	8	cABDEF	7 8 8	ACDES ABCD ABCE	D
12SR7GT	8	cABDEF	7 8 8	ACDES ABCD ABCE	T D D
12SW7	8	cABDEF	10 11 11	ACDEFS ABCDF ABCEF	T D D
12SX7	8	cADEFBS	7	ABCF ABCDES	T
12V6GT	8	ABCDEF	5	C	
12W6GT	8	ABCDEF	3	C	
12X4	8	bgnF	4	BFGNS BGN	D
12Z3	8	ABCDEF	3	В	
14	8	ABCDEF	2	C	

12CR6 to 14

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Short Test	Tube
14A4	8	ABCDEF	5	C	
14A5	8	ABCF	7	C	
14A7/12B7	8	ABCDEF	5	C	
14AF7	8	ABCDEF	7	A C	T
14B6	8	cdABEF	7	CD	
14B8	8	ABCDEF	11 7	BCD ACEF	M Os
14C5	8	ABCDEF	5	C	
14C7	8	ABCDE	5	C	
14E6	8	cdABEF	7 8 8	CDEF ABCDE ABCDF	T D D
14E7	8	ABCDEF	6 11 11	BCD ABCEF ACDEF	PDD
14F7 ·	8	ABCDEF	7	A C	T
14F8	8	agmBDEF	6	ABEMR ADEFGMS	1
14H7	8	ABCDEF	3	C	
14J7	8	ABCDEF	5	C	
14N7	8	ABCDEF	7	A	T
1407	8	ABCDEF	2	C	
14R7	8	ABCDEF	5 11 11	BCD ACDEF ABCEF	P D

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
1457	8	ABCDEF	4 4	ACDE BC	T Hp
14W7	8	cdABEF	4	CD	
14X7	8	cdABEF	4 4 4	ABCDE ABCDF CDEF	D D T
14Y4	8	ABCDEF	7	BC CF	D
14Z3	8	ABCDEF	3	В	
15	2	ABCDEF	6	C	
17	8	ABCDEF	6	C	
18	8	ABCDEF	7	C	
19	2	ABCDEF	6	AD BC	T
19AU4	9	cAE	4	AC	
19BG6G	9	ACE	5	A	
1908	9	ghABCDCEF	5 5 5 2	ABCEFGH BCDEFGH ACDEFGH ABCDEGH	D D D T
19J6	9	bnAEFG	3	ABGNSE BGNF	T
1978	9	ABCDF	10 7 5 5	ABC ACF BCF ABCEF	T D D D
19V8	9	BE	6 3 3	DE ABE ABDEF	T D D

14A4 to 19V8

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
20	4	ABCDEF	4		
20J8	10	ABCDEF	2	BCE ACD*	Hp
22	4	ABCDEF	12		
24A	3	ABCDEF	7	C	
25A6GT	10	ABCDEF	5	C	
25A7GT	10	ABCDEF	2 2	ACDEF BCF	DP
25AC5GT	10	ABCDEF	5	C	
25AV5	10	ABCEF	1	A	P
25AX4	10	cA	4	AC	D
25B5	10	ABCDEF	7	C	
25B6G	10	ABCDEF	1	C	
25B8GT	10	ABCEF	5 5	B	T P
25BK5	10	ABCEF	4	В	
25BQ6GT	10	CDE	1	C	
25C6G	10	ABCDEF	3	C	
25CA5	10	bnĀĒFG	3	BNR	
25CU6	10	ACDEF	4	C	P
25D8GT	10	ABCDEF	2	F	
25DN6	10	ACE	3	A	
25DQ6	10	ACDEF	4	C	
25L6GT	10	ABCDEF	2	C	
25N6G	10	ABCDEF	6	C	

^{*}Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
25\$	2	ABCDEF	9 14 14	BD ABC ACD	T D D
25W4GT	10	cAE	3	AC	
25X6 GT	10	ABCDEF	7 7	C	D
25Y4GT	10	ABCDEF	2	C	
25Y5	10	ABCDEF	7 7	ABD BCD	D
25Z4GT	10	ABCDEF	1	C	
2575	10	ABCDEF	3	ABD BCD	D
25Z6GT	10	ABCDEF	3	ACD CDE	D
26	1	ABCDEF	13		
26A6	10	bnAEF	3	BGNS	
26A7	10	bACDEF	3	ABD BCF	P
26BK6	10	bnEFG	14 8 8	ABEFNRT ABEGN ABEGN	T D D
2606	10	bnAEFG	10 11 11	ABEFNRS ABFGN ABEGN	T D D
26D6	10	bnAEFG	3	ABNRS	
27	3	ABCDEF	10	C	
28D7	10	ABCDEF	2	F	
28Z5	8	dhBCF	6	BCDH CDFH	D

TUBE TYPE	Fllament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
30	2	ABCDEF	4		
31	2	ABCDEF	4		
32	2	ABCDEF	4		
32L7GT	10	ABCDEF	3	ACDEF BCF	DP
33	2	ABCDEF	10		
34	2	ABCDEF	4		
35/51	3	ABCDEF	10	C	
35A5	10	ABCDEF	3	С	
35B5	11	bnrsAEF	3	ABNRS	
3505	10	bgnAEF	5	BGN	
35L5GT	10	ABCDEF	3	C	
35L6GT	10	ABCDEF	3	С	
35S 35S/51S	3	ABCDEF	7	С	
251114					

35W4

Test 1

0

Short Indicator Lamp will glow when switch is in position "B", and should go out when all switch-es are in center position.

Before Test 2, remove tube and set all indicated controls before reinserting tube.

Test 2 10 bgnpE

4 BGNP

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Teggle Switches Quality Test	Tube
35Y4					
Test 1	0	_		_	_
	wi po	ort Indicatonen all switsition, and stitch "D" is	ches	are in cer	nter
	all	fore Test 2, indicated c rting tube.			
Test 2	10	dAC	4	CD	
35Z3	10	ABCDEF	1 2	10	
35Z4GT	10	ABCDEF	1	C	
35Z5GT					
Test 1	0	_	_		
	pos sw Be	ort Indicatorien all swits sition, and s itch "A" is fore Test 2, indicated co	ches hould pushe	are in cer l go out weed.	ter hen
Test 2	10	aCE	3	AC	
35Z6G/GT	10	ABCDEF	2	C	D
36	6	ABCDEF	10	C	
37	6	ABCDEF	6	C	
38	6	ABCDEF	10	C	
39/44	6	ABCDEF	6	C	
40	5	ABCDEF	6		

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Tegale Switches Quality Test	Tube
40Z5/45Z5GT	0		_		_
Test 1					
	wh pos aw Be	ort Indicatorien all swife sition, and stitch "A" is properties of the state of the	ches hould pushe remo	are in cer l go out wed.	hen set
		indicated co	ontro	ls before r	ein-
Test 2	10	aCE	3	AC	
41	6	ABCDEF	7	C	
42	6	ABCDEF	7	C	
43	10	ABCDEF	7	C	
44	6	ABCDEF	6	C	
45	3	ABCDEF	7		
45A	3	AB	8		
45Z3	10	AFBD	4	D	
4575	0		_	-	_
Test 1	wh po:	ort Indicatorien all switesition and sitch "A" is	ches hould	are in ce	low nter hen
	all	fore Test 2, indicated co			
Test 2	10	aEC	4	AC	D
46	3	ABCDEF	7		
47	3	ABCDEF	6	C	
48	10	ABCDEF	3	C	
49	2	ABCDEF	6		
50	7	ABCDEF	6		

TUBE TYPE	Filament	Togale Switches Short Test	Control	Toggle Switches Quality Test	Tube	
50A5	11	ABCF	3	C		
50B5	11	bnrsAEF	4	ABNRS		
50BK5	11	ABCEF	4	В		
50C5	11	bnAEFG	5	BNR		
50C6G	11	ABCDEF	3	C		
50L6GT	11	ABCDEF	2	C		
50X6	10	ABCF	4	A C	D	
50Y6GT	11	ABCDEF	2 2	C		
50Y7GT Test 1 0 — — — — — — — — — — — — — — — — — —						
Test 2	11	IACDE	5 5	CL	D	
50Z7G	11	IACDE	5 5	DL CL	D	
51	3	ABCDEF	10	C		
52	6	ABC	10			
53	3	ABCDEF	7 7	ADE BCE	T	
55	3	ABCDEF	7 8 8	BCD ABC* ACD*	DD	

4075/ 45Z5GT to 55

^{*}Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
56	3	ABCDEF	2	C	
56A	6	ABCDEF	2	С	
57	3	ABCDEF	7	C	
58	3	ABCDEF	7	C	
59	3	ABCDEF	7	C	
64	6	ABCDEF	7	C	
65	6	ABCDEF	6	C	
67	6	ABCDEF	10	C	
68	6	ABCDEF	7	C	
69	6	ABCD	13	CD BC	T
70A7GT	11	cflADEF	3	CFL	
70L7GT	12	ABCDEF	3	ABDEF BCF	D BP
71	5	ABCDEF	10		
75	6	ABCDEF	7 8 8	BCD ACD* AEC*	D D
76	6	ABCDEF	2	C	
77	6	ABCDEF	7	C	
78	6	ABCDEF	7	C	
79	6	ABCDEF	5 5	ABD BC*	Ī
80	5	ABCDEF	4	A B	D D
81	7	ABCDEF	- 4		

^{*}Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
82	3	ABCDEF	4 4	A B	D
83	5	ABCDEF	4	A B	D
83V	5	ABCDEF	5 5	A B	D
84/6Z4	6	ABCDEF	7	AC BC	D
85	6	ABCDEF	7 8 8	BCD ABC* ACD*	T D D
89	6	ABCDEF	5	C	
95	3	ABCDEF	7	C	
99X	4	ABCDEF	9		
117L7/M7GT	13	ABCDEF	3	BCF ACDEF	BP D
117N7GT	13	mABDE	4	BM	
117P7GT	13	mABDE	2	BM	
117Z3	13	bnsF	3	BFNS	
117Z4GT	13	CE	3	C	
117Z6GT	13	BCDF	3	C	00
182B	5	ABCDEF	6		
183	5	ABCDEF	7		
482B	5	ABCDEF	6		
483	5	ABCDEF	7		
485	4	ABCDEF	7	C	

*Grid cap off.

TUBE TYPE	Filament	Toggle Switches Short Test	Control	Toggle Switches Quality Test	Tube
807	6	ABCD	4	C	
864	1	AB	12		
884	6	ABCDEF	3	C	
885	3	ABCDEF	5	C	
879	3	ABCDEF	2	T	
950	2	ABCDEF	4		
FM10000	6	ABCDEF	3	В	
1201	6	asBCDF	2	ADFS	
1203A	6	CD	4	C	
1204/7AB7	6	adfgmB	10	ABDFGMS	T
1221	6	ABCDEF	7	C	
1223	6	ABCDEF	7	C	
1229	2	ABCDEF	4		
1231	6	ABCDEF	1	C	
1232	6	ABCDEF	1	C	
1273	6	ABCDEF	5	C	
1275	5	AB	10	A B	D
1280	8	ABCDEF	5	C	
1284	8	ABCDEF	7	С	
1291	1	dhABC	4 4	ABDH CDFH	T
1293	1	AF	4		
1294	1	ACD	8	C	
1603	6	ABCD	7	C	
1611	6	ACDEF	7	C	

TUBE TYPE	Filament	Toggle Switches Short Test	Load	Toggle Switches Quality Test	Tube
1612	6	ABCDEF	7 5	ACDE C	Os M
1620	6	ABCDEF	7	C	
1621	6	ABCDEF	10	C	
1622	6	ABCDEF	7	C	
1626	8	ACE	4	C	
1629	8	ACDE	4	AC CD	TE
1631	8	ABCDEF	5	C	
1632	8	ABCDEF	1	C	
1633	8	csABEFG	6	ABCF ABCDE	T
1634	8	cABDEF	6	ABCH BCDE	T
1635	6	ABCDE	7 7	ACD BCE	T
1644	8	gIACDEF	4	ADEGL CEFGL	P
1654	1	klp	11	KLPT	
1851	6	ABCDEF	2	C	
1852	6	ABCDEF	3	E	
1853	6	ABCDEF	3	E	
2050	6	ABCE	1	C	
2051	†	ABCE	3	C	
9001	6	bnrAGEFS	2	ABGNS	
9002	6	bnreAGF	2	ABGNS	
9003	6	bnrAGEFS	2	ABGNS	

†Use 0 for SHORT TEST, and 6 for QUALITY TEST.

807 to 9003

Filament	Toggle Switches Short Test	Load	Togole Switches Quality Test	Tube Se tion
6	bnrsĀG	4	ABGNS	
3	ABCDEF	4		
1	AB	4		
6	ABCDEF	4	ADEF BCEF	T ₁
1	cABDEF	6	AC AM	T
8	ABCDEF	7 7	A C	T
6	ABCDEF	8 8 4	ABCDE ABCDF CDEF	D D T
6	ABCDEF	5.	C	
	6 3 1 6	6 bnrsĀG 3 ABCDEF 1 AB 6 ABCDEF 1 CABDEF 8 ABCDEF	6 bnrsĀG 4 3 ABCDEF 4 1 AB 4 6 ABCDEF 4 1 CABDEF 6 8 ABCDEF 7 7 6 ABCDEF 8 4	6 bnrsĀĠ 4 ABGNS 3 ABCDEF 4 1 AB 4 6 ABCDEF 4 ADEF 4 BCEF 1 CABDEF 6 AC 6 AM 8 ABCDEF 7 C 6 ABCDEF 8 ABCDE 6 ABCDEF 8 ABCDE 7 C 7 C

9006 to XXL

TUBE	TOGGLE	TUBE	TOGGLE
4A1 B'last Tubes	R	42A2	C
6.126	GS CGS CG	4282	C D
6.129	GS	42HA 45-4001‡	G AS
0,127	CG		CS AS
6.133 6.135	G	45-4001-1‡	AES CS
7	R	45-4001-2‡	CS
9	R	45-4001-3‡	AS CS
33-3341-1	R AR ABR	45-4001-4‡	AS AES CS
33-3377	F CF	45-4001-5‡	CS
33-3391	G GA	45-4001-6‡	AS CS
40	GS D	45-4001-7‡	AS AES CS
40A1	SG	45-4001-8‡	CS
40A2	D F	45-4001-9‡	AS CS
40B1	SG	45W‡	D
40B2	CANNOT BE TES ED	46A1	C
40W	D	46A2	C
40X300	D		D
42A1	C	46B1	R

1A1 to 46B1

^{\$} See Note B before testing tube.

TUBE	TOGGLE		TUBE	TOGGLE
	-			SWITCHES
46B2	C		55A1	D
	D		55A2	C
49A1	C	C AL THE STATE OF		D
49A2	C		55B2	C
4982	C		55KB	A
49KB	A		60R30-G	D
	G			F
49KC	A G		69.2033	A G
49KD	GS CGS		69.2037	A
4710	CG		80A1	D
49LB	A		80A2	C
	G		OUAZ	D
59LC	A		80B2	C
-				D
49LD	GS		85LC	A
	CG		86A1	D
50	D		86A2	C
50A2	D		OUAZ	D
50B2	D		86B2	C
	F		0002	D
50W	D		92A1	D
50X3	D		92A2	C
50X3T	D			D
	F		92B2 °	C
50X300	D			D

			1
TABE	TOGGLE	TUBE	TOGGLE
95K2	A G	135K1A	D G
100.37	D G	140L44	DS ADS AD
100.38	D G	140R	R
100.70	AM GM	140R4	BHR BGS
100.77	В	140R8	BHR BGS
100.79	В		DS
100.81	G	140R44	ADS AD
115.14	GS CGS CG	150R	DS ADS AD
115.22	GS CGS CG	160LB	A G
115.28	GS CGS CG	160LC	A G
115.40	G	165KB	A G
115.41	A G	165LB	A G
115.42	GS CGS	165LC	A G
135K1	CG A G	165L44	DS ADS AD

46B2 to 165L44

TUBE	TOSGLE SWITCHES	TUB	TOGGLE SWITCHES
165R	R	2903	A
165R4	BHR BGS	2904	G
165R8	BHR BGS	2905	G
180KB	A	3035	G
	G	3033	
1 85KB	A G	3326	GS CGS CG.
185KD	GS CGS CG	3334	DS ADS AD
185LB	A G	3334A	DS ADS
185LC	A		AD
185144	DS	3613	A G
	ADS AD	5502	D G
185R	R	5503	D
185R4	BHR BGS		G
185R8	BHR	5510	D F
	BGS	5512	D
185R44	ADS AD	5514	A
340	D	5515	A
878R48	D	3313	G

TUBE	TOGGLE	TUBE	TOGGLE
5516	A G	5534	A G
5517	GS CGS	5535	A G
5518	GS CGS	5536	A G
	CG	5537	A G
5519	A G	5538	A
5520	A G	5539	A G
5521	A G	5540	A
5522	A G	5541	G
5523	A G	5542	A G
5524	A G	5543	GS CGS CG
5525	A G	5544	A
5527	A G	5547	G
5530	A G	5548	G
5532	A		GS
5533	A	5549	CGS

165R to 5549

TUBE	TOGGLE SWITCHES	1	TUBE	TOGGLE
5550	A G	558	30	A G
5551	D G	558 558		G
5552	A G			D AG
5553	A G	558	36	ACG CFG
5555	A G	558	37	GS
5556	A G			GS
5561	A G	558	88	CGS
5562	A G	558	89	GS
5563	A G	559	90	CG
5567	CGS CGS	559	92	CDD
5571	D	559	93	C
5574	A G	559	95	D
5576	D	559	96	D
5577	D F	33	,,,	D
5579	A	559	97	CGS CGS

TUBE	TOGGLE	TUBE	TOGGLE
5598	C	5612	D F
5600	D F	5613	AG ACG CFG
5601	D F	5614	D
5602	D F	5615	D
5603	DS ADS AD	5616	DS ADS AD
5604	A G	5617	DS ADS
5605	DS ADS AD	5618	D F
5606	D F	5619	D F
5607	D F	5620	D F
5608	DS ADS	5622	A G
5609	AD A	5623	A G
	G DS	5624	A G
5610	ADS AD	5625	A G

to

TUBE	TOGGLE	T	VPE VPE	TOGGLE
5626	GS	5649)	A G
5629	CG A G	5651		AG ACG CFG
5630	GS CGS CG	5652	2	GS CGS CG
5422	GS	5653	3	G
5633	CGS CG AG	5654	1	AG ACG CFG
5637	AG ACG CFG	565	5	AG ACG CFG
5638	AG R	5656	5	AG ACG CFG
5640	AG ACG CFG	5657	7	A G
5641	AG ACG CFG	5658	3	GS CGS CG
5644	GS CGS	5660		A G
5647	CG	5662	2	D
3041	G	5663	3	D
5648	A			G
	G	5664	4	G

TUBE	TOGGLE	TURE	TOGGLE
5666	AG R	5695	A G
5667	A G	5696	A G
5675	A G	5697	A G
5676	A G	5698	A G
5679	G		GS
5681	C	5699	CGS
5682	C	F700	CG
5683	C	5700	AG
5684	G	5701	G
5685	G	3/01	AG
5686	G	5702	ACG
5687	G	STOL	CFG
5689	A G	5703	A G
5690	AG R	5704	AG R
5691	AG R	5705	GS CGS
5692	D		CG
	G	5707	A
5/02	AG	F700	G
5693	ACG CFG	5708	A G
5694	D G	5710	A

to

TUBE TYPE	TOGGLE	TUBE	TOGGLE
5711	AG ACG	819662	A G
5712	CFG	A16040	A G
5714	AG ACG	BK42C	A G
8589	CFG A	BK42D	GS CGS
8593	G	BK49C	CG A
	G		GS
8598	A G	BK49D	CGS
16032	A G	BK49D-10	GS CGS
16035	A G	BK55B	CG
16036	A G		A G
16039	A G	BK55C	A G
38710	A G	BK55D	GS CGS
45788	G		CG
69-2033	A G	BKU126D	R AR ADR
69-2037	A G		ABDR ABCDR

TUBE	TOGGLE	TUBE	TOGGLE
BKU172B	DRS BDRS	K40C	A G
BKV51DJ	BCDRS R AR	K40D	CGS CGS
נחוכאש	ABR ABCR	K42B-BG	A G
BKX11BJ	AR ARB	K42C-CG	A G
BKX21BJ	ARS ARS AR	K42D-DG	CGS CG
BL42B	ARB	K42E	GS CGS CG
BL42C	G A		ECG
BL42D	G GS CGS CG	K42E1	CGS CG ECG
BL49B	A	K43B	A G
BL49C	A	K43B2	A G
DI 40D	GS	K49B	A G
BL49D	CGS	K49C	A G
G133	D		GS
K13T56	A G	K49D	CGS

5711 to K49D

TUBE	TOGGLE	TUBE	TOGGLE	
K50C	A G	L495.5C	A	
K54B	A G	MT30A	A G	
K55B-BG	A G	YTU9	A G	
K55C	A	YTD16040	A G	1915-1
K55D	GS CGS CG	W143357 XB90	G D	WEGG
KY49C	A G		F	K50C to XB90
L42B-BG	A G			
L42C-CG	A G			
L42D-DG	GS CGS CG			
L49B	A G			
L49C	A G			
L49D	GS CGS CG			
L455.5C	A G			

REPLACEMENT PARTS LIST FOR PHILCO MODEL 7051 TUBE TESTER

Reference

Symb	ol Description	Part No.
C100	Condenser, .1 mf, 400 volts	61-0113
I100	Lamp, pilot	34-2085
N100	Lamp, neon	34-2482
R100	Resistor, 10,000 ohms ±5%, 1/2 watt	66-3108240
R101	Resistor, 390,000 ohms ±10%, 1/2 watt	66-4398340
R102	Resistor, 22,000 ohms ±5%, ½ watt	66-3228340
R103	Resistor, 1300 ohms ±5%, 1/2 watt	66-2138240
R104	Resistor, 200 ohms ±5%, 1/2 watt	66-1203240
R105	Resistor, 5100 ohms ±5%, ½ watt	66-2518240
R106	Resistor, 8200 ohms ±5%, 1/2 watt	66-2828240
R107	Resistor, 220 ohms ±5%, 1/2 watt	66-1223240
R108	Resistor, 10 ohms ±5%, ½ watt	66-0103240
R109	Resistor, 18 ohms ±5%, ½ watt	66-0183240
R110	Resistor, 5.1 ohms ±5%, ½ watt	66-9513240
R111	Resistor, 10 ohms ±5%, ½ watt	66-0103240
R112	Resistor, 18 ohms ±5%, 1/2 watt	66-0183240
R113	Resistor, 36 ohms ±5%, ½ watt	66-0363240
R114		66-1113240
S100	Toggle-switch-and-rivet assembly	76-5518
	Toggle switch (9 required) Toggle-switch knob	42-1584 27-4781
	Toggle-switch mtg. plate	56-2693
S101	Switch, filament selector	42-1583
S102	Switch, line adjustment	42-1594
S103	Switch, test	42-1588
	S103A: Part of S103	
S104	S103B: Part of S103 Switch, load selector	42-1764
8104	S104A: Part of S104	44-1104
	S104B: Part of S104	
T100	Transformer, power	32-8118
X100	Socket, 5-prong bantam	27-6147
X101	Socket, 4-prong	27-6110
X102		27-6111
X103		27-6112
X104	Socket, 7-prong	27-6155
X105		27-6114
X106		27-6148
X107		27-6146
X108	Socket, 9-prong-jumbo miniature	27-6203-9

MISCELLANEOUS

Description	Part No.
Socket, octal (rectifier)	27-6199
Socket mounting bracket	56-2694
A-C cord	L-3337
Meter	45-3013
Lugs (meter mounting)	L1843FE9
Knob (4 required)	54-4281
Grid-cap-and-lead assembly	76-1965
Lamp socket (neon lamp)	27-6210
Bull's-eye, lamp-socket assembly (pilot)	76-1658
Terminal-panel assembly	76-5519
Front-panel assembly	56-2692
Housing assembly	76-1666
Nameplate	56-3106
Felt foot (8 required)	54-4240
Switch-key plate (2 required)	56-3099
Log-folder assembly	76-2426
Ball strike	56-3748

